




NO.	DESCRIPTION	NO.	DESCRIPTION
01	Bolt	47	Spring
02	Top Cap	48	O-ring
03	Spring	49	Back-up Ring
04	Bolt	50	High Pressure Valve Bolt
05	Packing	51	C-ring
06	Cylinder Tube	52	Bolt
07	Reservoir Cap	53	Valve Cartridge
08	Back-up Ring	54	Steel Ball
09	Bolt	55	Stud
10	Air Piston A	56	Spring
11	Change Piston	57	Screw
12	Spring	58	Bolt
13	O-ring	59	Air Inlet Valve Seat
14	O-ring	60	Filter
15	Air Piston B	61	Air Inlet Valve
16	Piston Extension Spring	62	O-ring Washer
17	Pump Piston	63	Air Inlet Valve Cap
18	O-ring	64	Bolt
19	Piston Cylinder Cap	65	O-ring Washer
20	O-ring Washer	66	Spring
21	Pump Cylinder Cap	67	Silencer A
22	Back-up Ring	68	Oil Outlet Valve Seat
23	U-cup Ring	69	Foot Pedal Axle
24	Pump Cylinder	70	C-ring
25	O-ring	71	Bolt
26	Hydraulic Base	72	Bolt
27	C-ring	73	Washer
28	Oil Inlet Valve Stud	74	Foot Pedal Stop Washer
29	Spring	75	Silencer B
30	Steel Ball	76	Wiper
31	Oil Inlet Valve	77	Cover
32	Filter	78	Bolt
33	C-ring	79	Air Ventilation Needle
34	Release Valve Bolt	80	Pin
35	O-ring	81	O-ring
36	Spring	82	Air Ventilation Bolt
37	Release Valve Base	83	Packing A
38	O-ring	84	Packing B
39	Back-up Ring	85	Oil Packing
40	Steel Ball Axil	86	Oil Container
41	Release Valve	87	Foot Pedal
42	Steel Ball	88	O-ring
43	Spring	89	O-ring
44	O-ring	90	Filter
45	Back-up Ring	91	C-ring
46	Oil Inlet Valve		